



RECOMMENDED MUNICIPAL ORDER

QUANTITY	DESCRIPTION
1	6"-10" FLOW THRU PACKER
1	FERNCO AIR REGULATOR ASSEMBLY
1	FERNCO FLEX ADAPTER
20	FERNCO PUSH RODS 5' EACH
1	FERNCO PULL CABLE 500' EACH
AS REQUIRED	6" KIT (WINTER OR SUMMER)
AS REQUIRED	8" KIT (WINTER OR SUMMER)
AS REQUIRED	10" KIT (WINTER OR SUMMER)

RECOMMENDED PLUMBER ORDER

QUANTITY	DESCRIPTION
1	3" PACKER
1	4" PACKER
1	6" PACKER
1	FERNCO AIR REGULATOR ASSEMBLY
1	FERNCO FLEX ADAPTER
20	FERNCO PUSH RODS 5' EACH
1	FERNCO PULL CABLE 500' EACH
AS REQUIRED	3" KIT (WINTER OR SUMMER)
AS REQUIRED	4" KIT (WINTER OR SUMMER)
AS REQUIRED	6" KIT (WINTER OR SUMMER)

RECOMMENDED CONTRACTOR ORDER

QUANTITY	DESCRIPTION
1	3" PACKER
1	4" PACKER
1	6" PACKER
1	6"-10" FLOW THRU PACKER
1	FERNCO AIR REGULATOR ASSEMBLY
1	FERNCO FLEX ADAPTER
20	FERNCO PUSH RODS 5' EACH
1	FERNCO PULL CABLE 500' EACH
AS REQUIRED	3" KIT (WINTER OR SUMMER)
AS REQUIRED	4" KIT (WINTER OR SUMMER)
AS REQUIRED	6" KIT (WINTER OR SUMMER)
AS REQUIRED	8" KIT (WINTER OR SUMMER)
AS REQUIRED	10" KIT (WINTER OR SUMMER)

**WHEN USING 48" PATCH KITS SUBSTITUTE THE 300' AIR HOSE FOR PUSH RODS.